




Xtract Pre-wash Alkaline

Standards

Directions for use

Product specifications

- Specific weight: **1.132**
- Colour: 
- pH: 
- Foaming: 
- Packaging:



Product designed for:

Each Doy Pack should be diluted with purified water. The Xtract DP Pre-wash Alkaline contains 1 L of product to be diluted with 4 L of purified water (1). ISTOBAL recommends using the "Xtract Mixing System" when preparing Doy Packs, as this device is automatically programmed to ensure that the chemical product is distributed evenly. Thanks to this equipment, chemical products can be fed to both Jet wash facilities as well as rollovers and wash tunnels, with only one device in a technical room.

The user should open the Doy Pack lid, pour the contents into the 'Xtract Mixing System' and follow the instructions in the equipment's user guide (2).

(1) Mixing the product with water that is not purified will alter the quality of the mixture and hence the quality of the wash.
(2) It is recommended to refer to the Xtract Mixing System user guide for more information.

Dosing system	Xtract Mixing System XMS
Mixture	1 L product + 4 L water
Recommended dosing	27 mL/min in rollovers 25 mL/min in high pressure centres

Product description

This product is designed specifically for pre-washing all types of dirt. Its impressive descaling power and excellent foaming properties ensure the highest standard of car wash.

Storage

Keep tightly closed, avoiding exposure to UV rays and extreme temperatures.
For more information, we recommend referring to the safety sheet.